

SETTING YOUR PERSONAL COMBINATION

The lock is preset to open at 0-0-0.

To reset the opening combination:

1. Press down the Reset Button (1) all the way to hear a click sound.
2. Rotate the dials to the number of your own combination, such as birthday, phone number... etc.
3. Depress Snap Hasp (2) fully once to release the Reset Button and hear a click sound.

The lock will open to your new own combination.

